

Hochlastzeitfenster 2022



Spannungsebene	Winter 01.12. - 28.02.	Frühling 01.03. - 31.05.	Sommer 01.06. - 31.08.	Herbst 01.09. - 30.11.
MS	07:00 - 09:30 10:15 - 13:15	07:15 - 09:00 10:15 - 12:30	07:15 - 09:00 10:15 - 12:30	08:15 - 09:15 10:30 - 12:30
MS/NS	09:30 - 12:30	07:30 - 09:30	10:30 - 11:30	09:30 - 12:00
NS	15:30 - 19:00 19:30 - 20:00	-	-	-